



DMXEtherGate used as Input for Visualizer

DMX Console



Back View

Front View



Computer running Capture
WYSIWYG, Arkaos or similar.

P.O. Box 282
Kew, Vic 3101
Australia
+61 39 819 2433 Tel
+61 39 819 2733 Fax

ENTTEC PTY LTD

ENTTEC USA
SALES AND INFO
337 Court Street
Brooklyn, NY 11231
888 454-5922 Voice/Fax

PLATE

70018-1

RISER DIAGRAM
DMXEtherGate used as Input for Visualizer

SCALE: n/a
Some elements drawn out of scale for clarity
DRAWING DATE: 4/16/2007

DRAWN BY: J KUMIN