ENTTEC

ENTTEC RDM Kit

The complete RDM toolkit



Born from the Open DMX USB interface the RDM PRO version is the ultimate USB DMX adapter for all computer based lighting needs including RDM capability

DISCLAIMER This brochure is for general marketing purposes only and should not be relied upon as being complete or accurate.

www.enttec.com

Controls . Lights . Solutions

ENTTEC PTY LTD
Head office: 7 Macro Court
Rowville VIC 3178 Australia
Tel: +61 3 9763 5755
Fax: +61 3 9763 5688
sales@enttec.com

ENTTEC EUROPE F22-26 Parkhall Business Centre 40 Martell Road London SE21 8EN, UK Tel: +44(0) 2070616210 sales@enttec.co.uk

ENTTEC AMERICAS 604A Cornerstone Ct. Hillsborough NC27278 USA Tel & Fax: (888) 454-5922 sales.americas@enttec.com

ENTTEC RDM Kit

RDM made easy!

The complete ENTTEC RDM Kit includes our latest USB PRO Mk2, enabled for RDM and a full license key to use the PRO MK2 with RDM Controller and RDM

▶ RDM controller features

- Detects all RDM devices and adds them to the list
- Detects any sub devices for a selected device
- View a detailed summary of the device
- Change DMX personality and DMX start address for the fixture
- GET and SET for all PIDs
- Monitor your fixture for any sensors with easy to view info
- Conforms to full ANSI E1.20 (2006) RDM standard
- Drag & drop RDM patching





► RDM sniffer features

- Captures all RDM/DMX packets and displays them live
- Processes packets as received for possible errors/timing delays
- Save the packet list for future usage & import later to compare
- Captures all RDM/DMX packets to disk for future use
- Identifies Flicker within captured DMX packets
- Breaks down RDM Packet into easily readable chunks
- Shows packet data per byte, on doble click
- Displays average, max and min values for RDM/DMX packets received

▶ Applications

• RDM product development



Dimensions

H 22mm / **W** 66mm / **D** 105mm **H** 0.86" / **W** 2.60" / **D** 4.13"

PART NUMBER

70531 - RDM KIT

► The Kit includes:

- DMX USB PRO Mk2 (70314)
- RDM License Dongle (70511)
- ENTTEC Zip Case (70317)
- USB Cable (50282)
- 5pin DMX Breakout cable (79146)
- 5pin DMX Terminator (79122)



Using our widely used RDM Applications, you can easily find, address and configure all supported RDM devices. Test your own RDM devices to ensure they conform to standards, or use this kit for many supported RDM commands